# JOYSTICK

┿


SPI



At the beginning of LAB2, we will give each one of you a <u>Digilent Pmod JSTK2 module</u>.

This can be connected to your Basys3 board through the Pmod connectors.







## How to connect the Joystick

Connect the Joystick with the provided cable to "JA", top row, paying attention to the VCC and GND position.







The Digilent Pmod JSTK2 module protocol is fully described in its <u>reference manual</u>.

In short, it uses the SPI protocol to receive "commands" and send back the "readings" of the Joystick position and the buttons state.



## SPI protocol

The <u>Serial Peripheral Interface (SPI)</u> is a very popular synchronous protocol for off-chip communication.

In its basic form it is composed by 4 signals:

- Serial CLocK (SCLK)
- Master-Out Slave-In (MOSI)
- Master-In Slave-Out (MISO)
- Chip Select (CS)



#### SPI IP-Core

While SPI is a simple protocol, describing it in VHDL is not immediate.

To ease your work, we will give you a "AXI4-Stream SPI" IP-Core, similar to the UART one.





#### SPI IP-Core


You will find the details of its behavior in the README file. In short:

- Whatever you send to S\_AXIS is sent to the SPI "slave".
- Whatever is received from the SPI "slave" is sent to you through the M\_AXIS interface.





To respect the timing of the Digilent Pmod JSTK2 module (see <a href="here">here</a>), use these parameters in the SPI IP-Core.






#### JSTK2 commands

Using this IP-Core, you can easily "talk" to the module, following the protocol described in the reference manual.

We suggest you to use the cmdSetLedRGB command so that, in a single command, you can get the position of the joystick and the state of the button, and control the LED color.



### JSTK2 commands - cmdSetLedRGB



1 = trigger button is currently pressed 0 = trigger button is not being pressed JOYSTICK: Joystick Center Button Status Bit 1 = joystick center button is currently pressed 0 = joystick center button is not being pressed